

| | | | | | |
|--|---|------------------------|---|---|-----------------------------------|
| ITEM: | OUTDOOR PATIO HEATER | | | | SERIAL NO.: |
| MODEL: | LFH-A | | | | |
| APPLIANCE CATEGORY: | I ₃₊ (28-30/37) | I _{3B/P} (30) | I _{3B/P} (50) | I _{3B/P} (37) | |
| TYPES OF GAS: | Butane | Propane | Butane, propane or their mixtures | Butane, propane or their mixtures | Butane, propane or their mixtures |
| GAS PRESSURE: | 28-30 mbar | 37 mbar | 30 mbar | 50mbar | 37mbar |
| OUTLET PRESSURE OF REGULATOR: | 30 mbar | 37 mbar | 30 mbar | 50mbar | 37mbar |
| TOTAL HEAT INPUT (H _s): (Q _n) | 11.0 kW (G30:800g/h; G31:786g/h) | | | | 12.0 kW (873g/h) |
| INJECTOR SIZE: | 1.75 mm for main burner 0.22 mm for pilot burner | | 1.55 mm for main burner 0.22 mm for pilot burner | 1.60 mm for main burner 0.22 mm for pilot burner | |
| The marking, for example, 1.75 on the injector, indicates that the size of injector is 1.75 mm | | | | | |
| COUNTRY OF DESTINATION: | NL | | | | |
| IDENTIFICATION CODE: | 0063BU7882 | | | | |

- Het gebruik van dit toestel in afgesloten ruimten kan gevaarlijk zijn en is **VERBODEN**. Deze heater is uitsluitend bestemd voor gebruik buitenshuis of in goed geventileerde ruimten.
- Een goed geventileerde ruimte moet minimaal 25% van het wandoppervlak open hebben. Het wandoppervlak is de som van alle wandoppervlakken.
- Lees de instructies voordat u dit toestel gebruikt. Het toestel moet worden geïnstalleerd volgens de instructies en de geldende lokale voorschriften.
- Houd brandbare materialen uit de buurt van de heater.
- Sluit na gebruik de kraan van de gasfles en/of de drukregelaar.



EU Importer
 Outmate BV
 d' Oldedijk 7A
 7951 LE Staphorst
 The Netherlands

OUTMATE
 MADE TO STAND OUT